

**INSTRUCTIONS:**

1. Punch out bank and fold at scores.
2. Fold up sides and interlock slotted tabs. Fold down the flaps on top and front inward.
3. Fold front upward inserting tab on sides and under roof.
4. Fold flaps on back inward.
5. Bring the back side and top up over the bank and insert tab into slit where the hood and windshield meet.

