Artist Use Only: do not delete the following information!

Art intended to print to the edge must extend 3/32" outside the brown die line.
Art NOT intended to print to the edge must remain 3/32" inside the brown die line.

This item includes STOCK graphics.

INSTRUCTIONS:

1. Punch out bank and fold at scores.
2. Fold up sides and interlock slotted tabs.
3. Fold up back side and fold the flap over the interlocked tabs.
4. Fold front side with roof over the top and insert flap inside.